



Maintenance of Smart Film

Always power the film off when cleaning and do not power on until 100% dry. Be careful not to disturb any electrical connections.

The best cleaner is a simple solution of water and a small amount of streak free detergent soap . Clean the window and then squeegee dry with overlapping strokes. You may also clean the film surface with any normal strength glass cleaner or isopropyl alcohol and a lint free yellow micro fiber cloth. Our poly vinyl surface is durable however if you could avoid harsh paper towels it would prevent light scratches and hazing over time. Products with ammonia will not damage the film if used in reasonable quantities. Do not use any abrasive cleaners, industrial strength glass cleaners and/or any other window cleaning tools that may scratch the window film. Remember, the surface of the film is scratch resistant not scratch proof.



Isopropyl Alcohol



Micro-Fiber Cloth